

## **Adding Additional Profiler Audio Cards**

The Profiler Server software supports up to 4 Profiler PCI audio cards.

Each Profiler PCI audio card supports 2 mono input streams or 1 stereo input stream.

To purchase additional cards, make sure your PC has enough free standard PCI slots (not PCI Express) and then simply purchase additional Profiler packages from your dealer.

To install additional cards, stop and exit the server, shut down the PC and add one card at a time, installing the driver that ships on the Profiler CD in the “Driver-Win2000” directory for each card installed.

The driver Windows XP tries to install by default does not support additional cards or the skim inputs, so the driver provided on the Profiler CD must be used.

Full instructions for installing the driver on Windows XP are provided in a separate .pdf document.